



## music line POWERIGEL Owner's Manual

Thank you for choosing the **music line** POWERIGEL.

The POWERIGEL is a mains distributor for high quality audio components. It is used in place of standard power leads and a conventional mains block to distribute electricity from a wall socket to a maximum of six, eight or eleven components (POWERIGEL 6, 8 or 11, respectively) with virtually no loss of quality. Components with two-pin connectors can be connected by means of an adapter.

The POWERIGEL is made with the same type of cable used by Naim Audio.

### Important Safety Instructions

- Keep the mains distributor away from water and high levels of humidity.
- Ensure that cables cannot be damaged or cut by sharp objects. In case of damage to the cables or any other part of the mains distributor, immediately disconnect the plug from the wall socket.
- Connect the mains plug only to an earthed wall socket with a mains supply of 230 volts AC.
- Connect the three-pole IEC connectors only to the mains inlet of audio components designed for a mains supply of 230 volts AC.
- Do not modify the mains distributor in any way as this may impair safety. Guarantee and liability claims of any kind shall be void if the mains distributor has been modified.

### Placement

Place the POWERIGEL on a hard, dry surface, making sure that it rests securely on the spike tips of the leaf-sprung feet and that the casing does not

touch any surfaces or other objects. This is of critical importance for the sound quality of the connected components as it reduces vibrations inside the mains distributor.

### Connection

Ensure that the power switches of your audio components are in the "Off" position. Plug the leads exiting from the sides of the POWERIGEL into the mains inlets of your audio components.

If you live in a country where wall sockets only have two contacts, use a socket tester or a similar device to determine which of the two contacts is live. One side of the POWERIGEL mains plug is marked with a white dot; connect the mains plug so that the pin on the marked side plugs into the live contact of the wall socket.

You can now switch on your components. Follow the above steps in reverse order to disconnect the POWERIGEL.

### Run-In Period

Like many high-end audio products, the POWERIGEL will take a few days to run in before it reaches its maximum performance level. The sound quality of your system will increase further during this period.

### Guarantee

Please contact your dealer or distributor for guarantee information.

### **Maintenance**

The **music line** POWERIGEL requires no maintenance or care. Should you discover a defect or experience any problems with the POWERIGEL, please contact your dealer, distributor or **music line**.

**music line** Vertriebs GmbH  
Hainbuchenweg 14–18  
21224 Rosengarten  
Germany

Telephone: +49 4105 77050

Telefax: +49 4105 7705029

E-mail: [info@music-line.biz](mailto:info@music-line.biz)

Web: [www.music-line.biz](http://www.music-line.biz)

### **CE Declaration of Conformity**

This product has been designed and manufactured in accordance with the relevant European standards.